

## How to use the Practice Camera lens

This is a real(non-working) camera lens that will teach you to find any hidden camera.

Line up the Practice Camera lens and the Camera Finder so they are all in straight line of eye sight. Looking through the red viewer you will see the red LEDs'reflection off the Practice Camera lens. Focus on the center of the Practice Camera lens glass and look for the red dot. Tilt the Practice Camera lens and the Camera Finder to see how the Lens reflection follows the red LED light source.



### Camera Lens Reflections

### Common Camera Hiding Locations:

Clocks, Chargers, AC Outlets, Light Bulbs, Fake Router, Smoke Alarm, Air Vents, Tissue

Box, Water Bottle, Picture Frames, Stuffed Animals, Books, Clothes Hook and Home

Decor Items

## BUG DETECTOR for Detecting Hidden Cameras


User Manual(September, 2022)

The Bug Detector is for personal privacy protection. It assists in finding and sweeping for unauthorized surveillance devices. Locate hidden cameras could be invading your private space at home, conference room and office or during travel and shopping etc...It's portable and easy to carry in your handbag, suitcase or briefcase.

Usage area: **Hotel** **AirBnB** **Home** **Dressing room**  
**Public toilet** **Gym**

### Product structure

Size: 23.8\*15.3\*1.5(CM)




- ① Charging Indicator
- ② USB Charging Port
- ③ Night Vision Detection Switch
- ④ Lens Finder Switch
- ⑤ Viewfinder(8.5x4.5cm)
- ⑥ Night Vision Detected Indicator
- ⑦ Night Vision Detector
- ⑧ Ultra Bright Red LEDs
- ⑨ Speaker

## In the box:

1 x Bug Detector    1 x User Manual    1 x USB Cable    1 x Practice Camera lens

## How to Detect the 940nm invisible infrared LEDs

- ① Press and hold the button A: Night Vision Detection Switch for 2 seconds to start;



### ② 940nm Invisible IR detection

- A. Once device's two Night Vision Detected indicators (red color) blink slowly = The 940nm Invisible IR Detect Mode.
- B. If the front two Night Vision Detected indicators (red color) become SOLID, there may be hidden cameras in that location as it is detection infrared light.
- C. Press and hold the button A: Night Vision Detection Switch for 2 seconds to turn off the 940nm Invisible IR Detect Mode.


## TIPS:

The Night Vision Detection is affected by sunlight, so use the product at night or during the day when the curtains are closed.

## How to Detect the Hidden Cameras' Lens

### ① Hidden Camera Lens Detection

- A. Press and hold the button B: Lens Finder Switch for 2 seconds to start.



- B. Look through the Viewfinder and slowly scan the suspected area to look for any cameras. (Short press the Len Finder Switch to change the speed of flashing LEDs [Solid, Fast, Slow, Slower].) The lens of the hidden cameras will appear as a bright red point of blinking light when illuminated by the LEDs. The included Practice Lens will indicate what you will be looking for.

- C. Press and hold the button B: Lens Finder Switch for 2 seconds to turn off the Hidden Cameras' Lens Detect Mode.

|                     |                 |
|---------------------|-----------------|
| Battery             | 600mA           |
| Power consumption   | 50mA            |
| Continuous use time | Around 10 hours |
| Charging time       | Around 2 hours  |